Read & Save
Assembly Instructions

SKU # 0853400910

1. Insert and thread socket assembly (B) into lamp assembly (A) until secure.
2. Gently pull additional cord from lamp assembly (A).
3. Remove the finial (E) from the harp (C).
4. Pinch and insert harp (C) into the harp fittings on socket assembly (B). Slide the caps on harp (C) over the fittings on socket assembly (B) to secure.
5. Install the bulb. Use only the recommended bulb types and wattages.
6. Place the shade (D) on harp (C) and secure with finial (E).



IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

CAUTION: Refer to the re-lamping label located near the lamp holder for recommended maximum wattage. Do not exceed recommended wattage.

WARNING: Do not attempt to replace the bulb while the lamp is plugged into a wall receptacle.

TROUBLE SHOOTING

1. If your lamp does not light, make sure the plug is fully inserted into the outlet and try the on /off switch again.
2. If the lamp still does not light, unplug and replace the bulb.
3. If you have any questions regarding this product please call,
   Toll Free: 1.877.537.8539.

Lea y Preserve
Instrucciones de Instalacion

SKU # 0853400910

1. Inserte y enrosque la unidad del portalámparas (B) en la unidad de la lámpara (A) hasta que esté firme.
2. Tire con cuidado el exceso de cable de la unidad de la lámpara (A).
3. Retire el remate (E) del soporte de horquilla (C).
4. Pinche e inserte el soporte de horquilla (C) en el acoplamiento para el soporte de horquilla de la unidad del portalámparas (B). Deslice los casquillos del soporte de horquilla (C) sobre el acoplamiento de la unidad del portalámparas (B) para asegurar.
5. Instale la bombilla. Utilice sólo los tipos y vatajes de bombilla recomendados.
6. Coloque la pantalla (D) en el soporte de horquilla (C) y asegure en su lugar con el remate (E).



INSTRUCCIONES DE SEGURIDAD IMPORTANTES

Esta lámpara portátil tiene una clavija tomacorriente polarizada (una terminal es más ancha que la otra). Como punto de seguridad, esta clavija entrará en un tomacorriente de una sola forma. Si la clavija no entra en su totalidad en el tomacorriente, invierta la clavija. Si después de hacer eso aun no entra, llame a un electricista calificado. Nunca use un cordón de extensión a no ser que se pueda insertar la clavija en su totalidad. No haga alteraciones a la clavija.

PRECAUCIÓN: Refiérase a la etiqueta ubicada cerca del sostenedor de lámpara que contiene información sobre el vatio máximo requerido. No exceda el vatio máximo recomendado.

ADVERTENCIA: No trate de cambiar la bombilla mientras la lámpara esté conectada a un receptáculo de pared.

SOLUCIÓN DE PROBLEMAS

1. Si la lámpara no se enciende, asegúrese de que el enchufe esté bien insertado en la toma e intentar el encendido / apagado de nuevo.
2. Si la lámpara sigue sin encenderse, desconecte y vuelva a colocar la bombilla.
3. Si usted tiene alguna pregunta acerca de este producto, llame gratis al: 1.877.537.8539.